Analyzing network reliability up to 800G



Impact of SNR thresholds on BER for Coherent and Non-Coherent transceivers

1

Intro and recap

2

Bit Error Rate dependency

4

Distance

5

Temperature

6

Live Demo

8

Take Away

Measuring Link Quality

- **BER** = Bit Error Rate
- **SNR** = Signal-to-Noise-Ratio
- Convenience of using decibels for **small** and **large** values
- (e)SNR vs OSNR:
  electrical vs **optical**

Data POV

$$BER = \frac{Number\ of\ Erroneous\ Bits}{Total\ of\ Bits}$$

Communication POV



2019

DigitalSignalProcessor

+ FEC
+ BERT
+ OSNR
+ ...



lab setup



FLEXBOX5
with
800G DD,
heat sink
and fan

DUTs* are

1. 100G QSFP28 Single Lambda DR 500m
2. 100G QSFP28 Single Lambda ER 40km
3. 400G QSFP-DD Coherent ZR low power
4. 400G QSFP-DD LR4 10km
5. 400G **QSFP112** DR4 500m
6. 800G QSFP-DD DR8 500m

*Device Under Test

Watch for attenuation with short cables!

CAUTION: you may damage the photodiodes of long range transceivers!

Shopping List:

1. The Transceiver

100G QSFP28 ER WITH DUAL CDR

40 km, λ1310 nm, LC-Duplex, Singlemode

Q.13S1HG.40
QSFP28
ER

- Universal QSFP28 Transceiver
- Use FLEXBOX to configure to almost any vendor
- For 100GBASE-ER Ethernet links
- Integrated Clock-Data-Recovery (CDR)
- PAM4 modulated signal
- Supported Data Rates: 106.25 Gbit/s
- Up to 40 km via Singlemode OS2
- LC-Duplex Connector

2. Fiber Cable (Drums)

10 and 20km G.652.D
@1310nm <= 0.35 dB/km

3. Attenuators

Q.13S1HG.40 attenuation calculation

fiber length + attenuator	cable (0.35 dB/km)	used attenuator
2 meter	about 0 dB	11 dB
10 km	3.5 dB	11 dB
20 km	7 dB	11 dB
30 km	10.5 dB	5 dB
40 km	14 dB	2 dB
50 km	17.5 dB	2 dB



TRANSMIT MIN/MAX PER LANE	4.5 dBm / 7.9 dBm
RECEIVER MIN/MAX PER LANE	-14 dBm / -3 dBm (overload) @100G
WAVELENGTH TX (TYPICAL)	1310 nm
WAVELENGTH TX (RANGE)	1308.1 - 1310.2 nm
WAVELENGTH RX (TYPICAL)	1310 nm

At least **11dB** attenuation is required to ensured safety

100G BER on attenuation



fiber length + attenuator	TX Power (dBm)	RX Power (dBm)
2 m 11 dB	+ 4.8	- 7.1
10 km 11 dB	+ 4.8	- 10.0
20 km 11 dB	+ 4.8	- 13.4
30 km 5 dB	+ 4.8	- 11.9
40 km 2 dB	+ 4.8	- 11.1
50 km 2 dB	+ 4.8	- 14.6

Q.13S1HG.40

IEEE 802.3db BER range : max. 2.4x10-4

Source [11]

About BER max. 2.4 x 10^{-4} b/s

- PreFEC value

$$BER = \frac{N_e}{B\,\Delta T}$$

- Assume N_e = 100 errors, B = 100 Gbps and BER = 1.0x10^{-12} b/s
  - gating time ΔT is about 16 min
  - But with BER = 2.4x10^{-4} b/s you get ΔT = **4 µs** !

Source [8]

lab setup with cooler (400G DD ZR)



heat sink taken from an old Cisco 800

source: [14]

roof top

detailed separation





workplace

The coherent DD with cooling



Note: cFEC

Fiber Length	TX Power (dBm)	RX Power (dBm)
2 m	-10.0	-10.2
10 km	-10.0	-11.7
20 km	-10.0	-13.1
30 km	-10.0	-14.9
40 km	-10.0	-16.7
50 km	-10.0	-18.5
60 km	-10.0	-20.9

OIF BER Range:
1.5×10^{-4} to 1.3×10^{-2}

Source [13]

The coherent DD without cooling



Note: cFEC

Fiber Length	TX Power (dBm)	RX Power (dBm)
2 m	-10.0	-9.2
10 km	-10.0	-11.6
20 km	-10.0	-13.3
30 km	-10.0	-15.0
40 km	-10.0	-16.7
50 km	-10.0	-18.6

OIF BER Range:
1.5×10^{-4} to 1.3×10^{-2}

What if we go over the specs, up to ~120°C ?

Note: example with 2 meter Fiber

What if we go over the specs, up to ~120°C ?



Note: example with 2 meter Fiber. Q.13S1HG.05

What if we go over the specs, up to ~120°C ?



Note: example with 2 meter Fiber

source: [15]

What if we go over the specs, up to ~120°C ?



Note: example with 2 meter Fiber

source: [15]

Behavior of SFP+ up to 250°C





Note: example with 2 meter Fiber

At constant temperature how much does time influence BER?



37.0 °C were reached after 4 min.

Example with Q.13S1HG.05, 2m cable and a fan with heat sink constantly cooling.
1 hour of BER measured.

Note: PostFEC values (KP4 FEC)

Initial BER recoverable?



after recovering
10 times worse!

Example with Q.13S1HG.05 and PostFEC values.


Transceiver Monitor
Temperature [°C]
BER [b/s]
OSNR [dB]
Time [s]
MacBook Pro
my python
QSFP28 DR
2m
jumper
flexbox5

live demo


Transceiver Monitor
Temperature [°C]
0.04
0.02
0.00
−0.02
−0.04
−0.05
0.00
0.05
Time [s]
BER [b/s]
10^1
10^0
−0.05
0.00
0.05
Time [s]
OSNR [dB]
0.04
0.02
0.00
−0.02
−0.04
−0.05
0.00
0.05
Time [s]

take aways

- BER on Direct Detection Transceiver (DDT, grey transceivers) depends on both temperature and fiber length
- BER is rolling average value, not an instant snapshot
- There isn’t so much margin above high Alarm Temperature and LOS
- Coherent Transceivers benefit more from the properties of light, but also require a DSP with more features for proper signal recovery
- Coherent Transceivers BER do not bother with temperatures changes, mainly on fiber length
- The specified BER values are defined in IEEE802.3df for such devices in general. for DDT: when your BER is fine OSNR won't be your enemy.

FLUX AI: ”Chinese take away box from a restaurant filled with noodles” !!!

take aways

- BER on Direct Detection Transceiver (DDT, grey transceivers) depends on both temperature and fiber length
- BER is rolling average value, not an instant snapshot
- There isn’t so much margin above high Alarm Temperature and LOS
- Coherent Transceivers benefit more from the properties of light, but also require a DSP with more features for proper signal recovery
- Coherent Transceivers BER do not bother with temperatures changes, mainly on fiber length
- The specified BER values are defined in IEEE802.3df for such devices in general. for DDT: when your BER is fine OSNR won't be your enemy.



FLUX AI: ”Chinese restaurant take away box filled with tranceivers” !!!

FLEXOPTIX

Thank you

thomas.weible@flexoptix.net
gerhard.stein@flexoptix.net

References

1. SFF-8024, SFF Module Management Reference Code Tables, Rev. 4.10, November 24th of 2022
2. Rotary optical encoder model, https://commons.wikimedia.org/wiki/File:Encoder.jpg by Rrudzik (accessed Mar. 2024)
3. Everything You Need to Know About Complex Optical Modulation, Keysight (accessed Nov. 2024)
4. Fibre Sensing with and for Optical Networks, Ezra Ip et al., ECOC 2024 (Sept. 2024)
5. First Field Demonstration of Hollow-Core Fibre Supporting
6. Distributed Acoustic Sensing and DWDM Transmission, Ezra Ip et al., ECOC 2024 (Sept 2024)
7. Acoustic Sensing with Correlation and Coherent Detection using an Integrated Coherent Transceiver, André Sandmann et al., ADTRAN-ADVA (May 2023)
8. Fiber Optic Communications, Gerd Keiser, ISBN 978-981-33-4667-3 (Newton Center, MA 2021)
9. Understanding EVM, Paul Denisowki, Rhode&Schwarz, https://cdn.rohde-schwarz.com.cn/pws/dl_downloads/premiumdownloads/premium_dl_pdm_downloads/3683_8038_52/Understanding-EVM_wp_en_3683-8038-52_v0100.pdf, Version 01.00 (accessed Nov 2024)
10. Understanding FEC and Its Implementation in Cisco Optics, https://www.cisco.com/c/en/us/products/collateral/interfaces-modules/transceiver-modules/implementation-optics-wp.html, (May 13, 2022)
11. IEEE Standard for Ethernet, Amendment 3: Physical Layer Specifications and Management Parameters for 100 Gb/s,200 Gb/s, and 400 Gb/s Operation over Optical Fiber Using 100 Gb/s Signaling, (802.3db-2022)
12. IEEE Standard for Ethernet, Amendment 9: Media Access Control Parameters for 800 Gb/s and Physical Layers and Management Parameters for 400 Gb/s and 800 Gb/s Operation, (802.3df-2024)
13. OIF-400ZR-02.0, Implementation Agreement 400ZR, www.oiforum.com (November 3, 2022)
14. Smiley from the sMirC-series. Hot, https://commons.wikimedia.org/wiki/File:SMirC-hot.svg
15. Common Management Interface Specification 5, (CMIS) (November 2021)
16. Electrical Interface Optic Type Data rate FEC Standard Clause, Cisco (November 2024)